


# ADJUSTABLE ISOLATION RAIL INSTALLATION INSTRUCTIONS



1. SET ISO-RAIL WHERE REQUIRED BASED ON CONSTRUCTION DRAWINGS.  
**IMPORTANT!!! CONFIRM ORIENTATION, AS SPRINGS ARE SELECTED AND LOCATED BASED ON EQUIPMENT WEIGHT DISTRIBUTION.**
2. ATTACH SPRINGS TO BUILDING STRUCTURE USING MOUNTING HOLES PROVIDED.
  - REFER TO PROJECT SPECIFIC CERTIFIED CALCULATIONS SHEET FOR ATTACHMENT
  - IF CALCULATION SHEET IS NOT APPLICABLE, USE 1/2" DIAMETER TYPE A-307 BOLTS FOR STEEL ATTACHMENT OR 1/2" DIAMETER HILTI EXPANSION ANCHORS FOR CONCRETE ATTACHMENT.
3. SET AIR HANDLER ON RAILS, INSURING UNIT IS CENTERED.  
**IMPORTANT!!! CONFIRM ORIENTATION, AS SPRINGS ARE SELECTED AND LOCATED BASED ON EQUIPMENT WEIGHT DISTRIBUTION.**  
ATTACH UNIT TO RAILS USING THE PROVIDED UNIT ATTACHMENT CLIPS AND SCREWS.
4. ADJUST SPRINGS:
  - TURN ADJUSTABLE VERTICAL RESTRAINT NUTS 10-15 TURNS COUNTERCLOCKWISE
  - TURN ADJUSTMENT BOLT 2-4 TURNS COUNTERCLOCKWISE TO RAISE/LEVEL UNIT
  - REPEAT PROCESS AT EACH POCKET LOCATION UNTIL UNIT IS LEVEL AND SUPPORTED BY SPRINGS
  - SPACE BETWEEN MOUNTING PLATE AND RESTRAINING PLATE TO BE 1/4"-1/2"
  - TURN ADJUSTABLE VERTICAL RESTRAINT NUTS CLOCKWISE UNTIL FINGER TIGHT